

No. TB-19 / September 2010

---

## Apple iOS4 with SonicHub

Please be advised that Apple iPod Touch® and iPhones® running Apple iOS4 may need a software update to operate correctly with the Lowrance SonicHub.



### Overview

iPod Touch and iPhones running iOS4 may experience problems playing audio through the SonicHub. The Lowrance HDS multifunction displays may show that the current audio track is playing, but there may not be any audio present.



*Note: Before completing the following steps sometimes the iPhone or iPod may not be fully docked correctly. To make sure that this is not the case: remove and re-dock your device. If the audio begins to play then you do not need to proceed with the following instructions.*

### Resolution

To remedy this issue you need to upgrade your Apple device via iTunes® to iOS4.1.

- Connect your Apple device to your computer using the supplied Apple USB cable.
- When iTunes opens select your device from the Source list
- Select Check for Update.
- Click Download and install.
  - <http://www.apple.com/ipodtouch/software-update/>
  - <http://www.apple.com/iphone/software-update/3>
- After iTunes has updated your device **make sure you power the device down then back on.**
- If you still are experiencing no audio you may need to reset your device.
  - To do this, hold the home key below the screen and the power key on the top right until the silver Apple logo appears.